

Scooter Service & Support

Rev Maintenance & Service

Removing Standing Platform

Hand Brake Assembly Replacement

Handlebar Assembly Replacement

Grips Replacement

Bell Replacement

Stem Catch Replacement

Secondary Lock Replacement

Brake Maintenance Instructions

Cleaning the Charging Port

Front Fender Replacement

Kickstand Replacement

Tire & Tube Replacement

Motor Assembly Replacement

Skid Rail Replacement

Battery Replacement

Headlight Replacement

Removing Standing Platform

Difficulty Rating: 1

Estimated Time: 5 minutes

Tools you will need:

- 4mm hex key



1. Remove the four standing platform securing screws using a 4mm hex key. Two of these screws are located at the rear of the standing platform, while the other two screws are toward the front of the standing platform and accessible by lifting up the crescent-shaped cutouts in the deck pad.



2. Remove the standing platform, making sure not to lose any of the rubber grommets which are inserted into the four holes on the standing platform. Note that there is an individual grommet inserted into both sides of each hole on the standing platform (total of 8 grommets).



3. Re-attach the standing platform by re-installing the four screws from earlier. Do not overtighten these screws. It is only necessary to tighten them until they are snug.



Was this article helpful?

5 out of 5 found this helpful

Comments

0 comments

Article is closed for comments.

Help

Can't find what you're looking for?

SUBMIT A REQUEST

Company

Contact Us

Press

Careers

Terms and Conditions

Privacy Policy

Safety and Compliance

Explore

Community

Reviews

Videos

Dealer Locator

Orders

Shop Boards

Accessories

Support

Subscribe to our Newsletter

