



QUICK  
START  
GUIDE





## WARNING



### RISK OF DEATH OR SERIOUS INJURY

Whenever you ride a Boosted board, you risk death or serious injury from loss of control, collision, and falls. To ride safely, you must read and follow all warnings and instructions in the manual and at [www.boostedboards.com/training](http://www.boostedboards.com/training).

Always wear a helmet when riding. Avoid water, wet surfaces, slippery/uneven surfaces, steep hills, traffic, cracks, tracks, gravel, rocks, or any obstacles that could cause a loss of traction and cause a fall. Avoid night riding, areas with poor visibility, and small spaces.

**WARNING:** Do not ride Boosted in environments, on inclines, or at speeds where you would not be safely in control of an unpowered longboard. In the event of wireless interference or battery fault, you may need to rely on skating techniques like footbraking or sliding to stop. For more information, visit the online tutorials at [www.boostedboards.com/training](http://www.boostedboards.com/training).



#### **WARNING: AVOID WATER!**

Your Boosted board is not waterproof. Electronics, bearings, and other components can be damaged. Water damage is not covered under the warranty.



#### **WARNING: PINCH POINTS!**

Keep fingers, hair, and clothing away from belts, motors, wheels, and all moving parts.




#### **WARNING: RISK OF ELECTRIC SHOCK!**

Do not open or tamper with electronics housings, which also voids the warranty.

**YOU ARE BOOSTED:** Please ride responsibly and respect those around you, both for your safety and to help promote our new sport and mode of transportation.




# REMOTE GLOSSARY



# B

## BOARD GLOSSARY



# 1

## GET READY

### • ALWAYS WEAR A HELMET.

• Find an open, flat area with clean pavement for your first ride.

• Read the warnings on the skateboard and at the beginning of this manual.

• For more details on skating, check out the online tutorials at [www.boostedboards.com/training](http://www.boostedboards.com/training).




### • OTHER PROTECTIVE EQUIPMENT IS HIGHLY RECOMMENDED.






**CLICK!**



AVOID THESE THINGS THAT CAN CAUSE SLIPPING:



AVOID THESE THINGS THAT CAN CAUSE TRIPPING:





AVOID THESE THINGS THAT CAN CAUSE COLLISIONS:



**ARE YOU A "REGULAR" OR "GOOFY" FOOT RIDER?**

If you are unsure, place the foot you kick a ball with in the back.

**REGULAR FOOTED**  
(left foot forward)**GOOFY FOOTED**  
(right foot forward)**STANCE:**


Your Boosted board has a lot of power. Follow these tips to ensure a safe riding experience:

- Move the Throttle Wheel in small increments.
- Keep a wide stance on the board,
- Keep a low center of gravity.
- Lean forward when accelerating.
- Lean backwards when braking.




**3****POWER ON/OFF THE REMOTE**


Press the Multi-Button for 2 seconds.

**4****POWER ON/OFF THE BOARD**


Press the Power Button for 2 seconds.





**5****CHECK THE REMOTE-BOARD PAIRING**

Connection and Mode Indicator will light when board is paired. If indicator is not lit, check that the board is powered on. If light is still not lit, then tap the Multi-Button **5 times** to pair your board or pair to a new board.


**6****CHECK THE REMOTE BATTERY LIFE**

**WARNING:** Never start a ride with a low remote battery indication.

# 7


## CHECK THE BOARD BATTERY LIFE


Click the Multi-Button **1 time (1x)** after paired with the board.




# 8

## OPERATING THE BOARD WITH THE REMOTE



**9****CHARGE THE REMOTE**

NOTE: If the remote is charged every time the board is charged it should take much less time to charge.

**10****CHARGE THE BOARD**

Warning: Never leave board unattended while charging.

# 11

## CHANGE THE RIDING MODE

This board ships in standard mode. Before following the instructions below to switch to expert mode, make sure you have mastered the use of the remote and board.

**WARNING:** The Throttle Wheel is much more sensitive in expert mode. To avoid getting thrown off the back of the board, follow these tips:


- Start by moving forward as slowly as possible
- Move the Throttle Wheel in small increments.
- Keep a wide stance on the board,
- Keep a low center of gravity.
- Lean forward when accelerating.
- Lean backwards when braking.



### TO TOGGLE MODE BETWEEN STANDARD AND EXPERT:

Tap the Multi-Button **3 times (3x)** until you hear an alert and lights flash.

- Slow blinking indicates standard mode
- Fast blinking indicates expert mode



Repeat this step to toggle between modes.

Note: The mode is indicated by the speed that the connection icon is flashing anytime the remote is paired with the board.



THERE IS MORE INFORMATION ONLINE.

This manual is a quick start guide intended for someone with some skateboard experience to get started. For more advanced riding techniques or more detailed tutorials on learning how to skate, please visit our website:

[www.boostedboards.com/training](http://www.boostedboards.com/training)

You can find even more information there on:

### **GETTING STARTED:**

- How to stand on the board
- How to turn
- How to find a good spot to practice

### **ADVANCED TECHNIQUES:**

- How to foot brake
- How to ride uphill and downhill safely
- What to look for in traffic

### **MAINTENANCE:**

- Pre-ride inspection
- Routine maintenance

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

# WARRANTY

## **LIMITED WARRANTY:**

This board is covered by a 90 day manufacturer's warranty that covers defects in workmanship and material. This does not cover damage caused by abuse, misuse, negligence, accident, or riding in water.

If the product has a manufacturing defect within 90 days of ship date, contact [warranty@boostedboards.com](mailto:warranty@boostedboards.com) before shipping the board back in order to get a return authorization.

## **FOR ALL RETURN and WARRANTY SHIPPING:**

Please keep your shipping box. The warranty does not include damage from shipping in insufficient packaging.



